



Electra-Ride Elite

Straight Rail Battery-Powered Stairlift

Flexible Seating

No matter what challenge you face, the Electra-Ride Elite seating can be adjusted to meet your needs. The seat height can be adjusted from 19" to 24.5". The footrest can also be adjusted to make the unit even more comfortable. The armrests independently flip up for easy wheelchair transfer.

Compact

Your guests will get up with ease after the unit is installed. *The Electra-Ride Elite rail is only 5" off the wall!* The seat and arms of the carriage flip up out of the way when the unit is not in use.

Clean Design

The unique yet simple design of the rail hides the mechanical components, keeping the grease and dust away from you and your clothes.



Reliable operation

The Electra-Ride Elite uses two 12-volt batteries that are continuously charged by a state-of-the-art battery charger that plugs into any household outlet. Our leading edge technology assures you access up and down the stairway even if the electrical service in your home is interrupted.

Safety

You will be totally at ease on your Electra-Ride Elite. When traveling on the stairs, the Elite will sense any obstacles and will automatically stop. When you want to get off the unit upstairs, the seat easily swivels so you face the hall. A retractable seat belt is standard. The Electra-Ride Elite meets all ANSI - A18.1 residential requirements, as well as all public building specifications with the optional commercial package.

Affordable

The Electra-Ride Elite provides a cleaner installation with no need to modify your home or install additional electrical outlets.



The arms, seat and footrest flip up, creating plenty of space for guests to walk up the stairs.



The Electra-Ride Elite's hidden rack and pinion drive system provides a smooth ride, without hesitation when the unit stops and starts.



Electra-Ride Elite

Straight Rail Battery-Powered Stairlift

Exceptional Value

- Locking swivel seat, at the top and bottom of the stairway.
- Two remote, wireless call/send controls.
- Generous seat size (20" between the arms).
- Footplate safety sensor and retractable seat belt.
- Charging station indicator lights at the top and bottom of the stairway.
- On-board diagnostics make service easier and more precise.
- Meets all ANSI - A18.1 requirements.

Convenient Installation

- Rail installs to within 5" off the wall.
- Can be installed on either side of the stairway with simple modification.
- Standard track lengths of 16', 20', and 24'. Custom lengths available.

Smooth, Powerful Drive System

- Self-locking worm gear, rack and pinion drive.
- Maximum rider weight of 400 lbs.
- Soft start, solid-state controller makes it possible to adjust the speed to the comfort of the user.

Battery-Powered Technology

- Ensures access, even during power outages.
- Powered by two 12-volt batteries, continuously charged by a 3 Amp battery charger that plugs into any 110-volt household outlet.
- Custom seat upholstery available

Comfort

- Adjustable seat height for easier entry/exit at the top and bottom of the stairway.
- Adjustable footrest height for added comfort.
- Flip-up arms for easy wheelchair transfers.
- Seat is contoured to provide optimum comfort.

Your lifestyle does not have to be limited by stairs.
So enjoy the home you love, upstairs and down.



The arms flip up out of the way for easy wheelchair transfers. The swivel seat lever is conveniently located under the arm.



The two wireless call/send controls make the installation simple and clean with no wires running along the wall.



WRIGHT & FILIPPISSM

For more information, please contact
the Lifts, Elevators & Ramps Department
(800) 482-0222 or (248) 829-8214
www.FirstToServe.com

These and other barrier-free services are available throughout the entire state of Michigan.